


QUICK-START MANUAL



⚠ Important Proper Installation Method


Proper Sensor Installation

⚠ Very Important
Lubricate O-rings with a Viscous Lubricant compatible with the system.

- ➔ Using an **Alternating | Twisting Motion** Carefully lower the sensor into the fitting. | Do Not Force
- ➔ Engage one thread of the sensor cap then turn the sensor until the alignment tab is seated in the fitting notch | Fig-1 | Ensure Tab is Parallel to Flow Direction.

⚠ Ensure Tab | Notch are Parallel to Flow Direction Fig-2

Hand Tighten the Sensor Cap. **DO NOT** use any tools on the sensor cap or the cap threads or fitting threads may be damaged, see Fig-1




Wiring | DC Power Only


- Use conductor shielded cable 24V DC (20-26 ANG).
- Cable shield must be maintained through cable splice.

⚠ 14-28VDC

● **4-20mA | RS-485 | Pulse Output**




● **Relay Outputs**



⚠ Important | Installation




Ensure Silicon Grease is Applied Prior to Insertion



⚠ Ensure Location Tabs Are Parallel to Direction of Flow

Correct Sensor Positioning



In Order to Achieve the Highest Accuracy Always Maximize the Upstream Downstream Distances Between the the Flow Meter and a Pump | Valve or Fitting.


Sensor Mounting Position

Horizontal Pipe Runs

- ➔ Mount sensor in the upright (0°) position for best performance.
- ➔ Mount at a Maximum of 45° when Air Bubbles are present.
- ➔ **Do not** mount on the bottom of the pipe when Sediments is present.


Vertical Pipe Runs

- ➔ Mount sensor in any orientation.
- ➔ Upward Vertical flow is Strongly Recommended to **Ensure Full Pipe.**




Maximum Operating Pressure/Temperature

- PP Body : (180psi @ 68°F) (25psi @ 176°F)
- PVDF Body : 200psi @ (-20 to 27°C) (-4 to 81 F)




Rotor Replacement Procedure

- To remove the rotor, insert a small screwdriver between the rotor and the ear of the sensor.
- Carefully Twist the screwdriver blade to flex the ear outward enough to remove one end of the rotor and pin.
- **DO NOT** flex the ear any more than necessary! If it breaks, the sensor cannot be repaired and will not be considered as a valid warranty claim.
- Install the new rotor by inserting one tip of the pin into the hole, then Carefully flex the opposite ear back enough to slip rotor into place.



PROGRAMMING STEPS

FRONT PANEL & KEY FUNCTIONS



LSS SERIES

Key Name	Symbol	Descriptions
Enter & Save Key		1. In the Measuring Status, Press this Key for 5 sec to enter Programming. 2. In the Measuring Status, Press this Key to Switch the Rate & Total Value. 3. In the Measuring Status, Press this Key to Save the Value & Go to Next Programming Screen.
Shift & Totalizer Reset Key		1. Press this Key for 10 sec to Reset the Total Value. 2. Pressing this Key will Move the Cursor Left.
UP Key & Relay Set Key		1. Press this Key for 5 Sec to Enter to Alarm Programming Screen. 2. Pressing this Key will Increase the Digits.

1. To modify the Settings, please press and press to save the Settings after the modification is made.


2. Remember the New Passcode If Changes Are Made!


3. In any Screen, press Together During programming Stage to Return Immediately to Home screen | Note : AFTER 2 min the Display will Return to Home Screen.

PROGRAMMING RELAYS

Follow  Hand For Programming

Alarm Setpoint



 Press   at the Same Time during Programming to Return to Home Screen.

ALARM RELAY | AL

When AL=HI, DELAY= 0 :

Current Value > Programmed Value (AL) + Hysteresis (HYS) → Relay On
 Current Value < Programmed Value (AL) - Hysteresis (HYS) → Relay Off

When AL=HI, DELAY= 1 – 99 sec.:

Current Value > Programmed Value (AL) + Hysteresis (HYS) + Delay Time (DEL) → (Relay On)
 Current Value < Programmed Value (AL) - Hysteresis (HYS) → (Relay Off)

When AL=HI, DELAY= -1 – 99 sec.:

Current Value > Programmed Value (AL) + Hysteresis (HYS) → (Relay On + (DEL) and then off)
 Current Value < Programmed Value (AL) - Hysteresis (HYS) → (Relay Returns to Normal State After the Procedure)

When AL=LO, DELAY= 0 :

Current Value > Programmed Value (AL) + Hysteresis (HYS) → (Relay Off)
 Current Value < Programmed Value (AL) - Hysteresis (HYS) → (Relay On)

When AL=LO, DELAY = 1 – 99 sec.:

Current Value > Programmed Value (AL) + Hysteresis (HYS) → (Relay Off)
 Current Value < Programmed Value (AL) - Hysteresis (HYS) + Delay Time (DEL) → (Relay On)


Follow Hand For Programming



Display	Descriptions	Default
Power On 10000	Measuring Status Current Flow Value. (Press 5 Sec)	
Press (5 Sec) AL1	To Move Cursor — To Increase or Decrease Pass Code (P.Cod) Press to enter Passcode.	00000
No P.Code Correct Yes Press ENT	If Pass-code is correct the Flow Meter will enter into Programming Status. If Passcode is incorrect the Display will to Return to Measuring Status.	
Press ENT	Press Enter Again	

NOTE

- There are Four (4) Programming Windows (1) "System Programming Group (SYS)" (2) "Alarm Programming Group (roP)" (3) "Analog 4-20mA Output Setting (AoP)" (4) "RS485 (Optional) Programming (doP)".
- Press to select each Section Screen Press to enter Programming page for modifying the parameters.



Programming Steps

Follow Hand For Programming


Display	Descriptions	Default
545 unit	Flow Unit Setting (Unit) Press to modify the Unit of measurement (Liter, Gal, Ton., m ³)	LTR
idC-t	Sampling Time Base (idC-t) Press to Change sampling time (0.5, 1.0, 2.5, 5.0 sec).	10
dPr	Decimal Point of Rate Setting (dPr) Press to select decimal point (0,1,2,3,4) (0 STD).	00000
dPt	Decimal Point of Total Setting (dPt) Press to select total decimal point (0,1,2,3,4) (0 STD).	00000
t-unit	Time Parameter Setting (t-unit) Press to modify time parameter (sec/min/hour) Minutes (Recommended)	SEC
K-F	K Factor Setting (K-F) Press to modify K Factor (0.1 - 999.999 Section See Fittings Section Page 8)	10000
Code	Passcode Setting (CodE) Press to modify passcode (0-19999). PS: Please don't forget the new passcode after Change.	00000
LoCK	Lock Setting (LoCK) Press to lock the keys, using key lock function allows only viewing of the programs, but any change any of the values will be blocked. No (Unlock), YES ("ENT" unlock).	no

Press at the Same Time during Programming to Return to Home Screen



Programming Relay Set Points


Display	Descriptions	Default
roP	Programming Relay Page (roP) The following steps are only available for alarm output.	
AL1	Alarm 1 Selection Setting (AL 1) Press to select alarm 1 (Flow Rate or Total).	RATE
AL2	Alarm 2 Selection Setting (AL 2) Press to select alarm 2 (Flow Rate or Total)	RATE
Act 1 Act 2	Alarm 1 (ACT1) Alarm 2 (ACT2) Alarm Relay Setting Press Change Relay Set Point Value that is \geq (Hi) or $<$ (Lo) for Relay action. Hi = Above Current Flow Lo = Below Current Flow	HI
HYS1 HYS2	Hysteresis 1 (HYS1) Hysteresis 2 (HYS2) Alarm Hysteresis Setting Press to modify the Hysteresis value, when Flow Rate runs below or above display value (depends on alarm action). Alarm setpoint \pm this value (0-999) will turn off the alarm. Note : If AL1.5 or AL2.5 are set to Alarm based on Total (see above) then the Hysteresis will be Disabled	00000
dEL1 dEL2	Delay Time 1 (dEL1) Delay Time 2 (dEL2) Alarm Run Delay Setting Press to modify the value, Based on Value Entered the Alarm will activate only when the Display Value is Reached and the time is passed Initial Start - Up - (Prevents False Alarms)	00000
Sdt	Alarm Start Band Time Setting (Sdt) Press to modify the value (0-99 sec), if the display value hits alarm start band value; the alarm will be active (sec). Initial Start - Up, Filter Change Out	00000



Programming 4-20mA Output


Display	Descriptions	Default
AoP	A/O Programming (AoP) 4-20mA The following steps are only available for 4-20mA output.	
AoSEL	A/O Selection Setting (Ao.SEL) Press to select 4-20mA output for Flow Rate or Flow Total.	RATE
AnLo	A/O Low Scale Setting (AnLo) Press to adjust A/O low scale to correspond to the display value (programmable). Ex: A/O is 4-20mA the display is 0 to output 4mA, this value must be set for 0	00000
AnHi	A/O High Scale Setting (AnHi) Press to adjust A/O hi scale to correspond to the display value (programmable). Ex: A/O is 4-20mA, the display is 90.0 to output 20mA, this value must be set for 90.0	99999
AZEro	A/O Zero Adjustment (AZEro) Press to select adjusting For Valves Above Flow Rate, press to modify the A/O zero. PS: Use this function to adjust the real A/O zero. i.e. if you wish to have 0mA read other than 0 i.e. 10 GPM	00000
ASPA n	A/O Span Adjustment (ASPA n) Press to select adjusting flow rate, press to modify the A/O span. PS: To use this function to adjust the real A/O span. i.e. Flow Rate 20mA =150 GPM. When you wish to Set a pre-determined Max Flow Value	00000

For Calibration Purposes Only



Note : All Sensors are Factory Calibrated - Calibration Not Required

CPVC TEE FITTING | SCH80



K-Factor | Pulse/Gal*


TEE FITTING			K-Factor CPVC SCH80	Sensor Length
Size	DN	Id		
1/2"	15	0.55	811	T
3/4"	20	0.74	430.3	T
1"	25	0.96	334.7	T
1-1/4"	32	1.30	188.6	T
1-1/2"	40	1.50	156.8	T

TEE FITTING			K-Factor CPVC SCH80	Sensor Length
Size	DN	Id		
2"	50	1.90	28.7	T
2-1/2"	65	2.30	19.6	T
3"	80	2.90	11.9	T
4"	100	3.83	6.3	T
6"	150	3.80	2.6	T1

*Divide K- Factor by 3.8 to change to LPM

K-FACTOR TABLES



CLAMP SADDLES



Clamp Saddles			K-Factor Pulse/Gal*	Sensor Length
Size	DN	Id	CPVC (SCH80)	
2"	50	1.9	29.0	T
2-1/2"	65	2.3	19.8	T
3"	80	2.9	12.0	T
4"	100	3.8	6.3	T
6"	150	5.7	2.6	T1

*Divide K- Factor by 3.8 to change to LPM

CPVC SOCKET WELD-ON ADAPTERS



Glue-On Adapters			K-Factor Pulse/Gal*	Sensor Length
Size	DN	Id	CPVC (SCH80)	
2"	50	1.9	29.0	T
2-1/2"	65	2.3	14.8	T
3"	80	2.9	12.0	T
4"	100	3.8	6.3	T
6"	150	5.7	2.6	T1
8"	200	7.0	1.4	T1

Glue-On Adapters			K-Factor Pulse/Gal*	Sensor Length
Size	DN	Id	CPVC (SCH80)	
10"	250	9.5	0.90	T1
12"	300	11.3	0.64	T1
14"	350	12.4	0.53	T1
16"	400	15.1	0.40	T1
20"	500	19.0	0.77	T1
24"	600	21.0	0.18	T1

*Divide K- Factor by 3.8 to change to LPM

Warranty Information

All warranty and non-warranty repairs being returned must include a fully completed Service Form and goods must be returned to Icon Process Controls directly or to the authorized distributor. Product returned without a Service Form will not be warranty replaced or repaired.

Truflo Flow Meters are warranted out of box but not against any damage, due to Process or Misapplication failures e.g. High Temperature | Chemical Attack or Physical Mishandling of Product.

Safety Information

1. De-pressurize and Vent System Prior to Installation or Removal.
2. Confirm Chemical Compatibility Before Use.
3. DO NOT exceed Maximum Temperature or Pressure Specifications.
4. ALWAYS Wear Safety Goggles or Face-shield During Installation and/or Service.
5. DO NOT Alter Product Construction.



Warning / Caution / Danger

Indicates a potential hazard. Failure to follow all warnings may lead to equipment damage, injury, or death



Hand Tighten Only

Overtightening may permanently damage product threads and lead to failure of the retaining nut.



Note / Technical Notes

Highlights additional information or detailed procedure.



Do Not Use Tools

Use of tool(s) may damage product beyond repair and potentially void product warranty.




WARNING!




Personal Protective Equipment (PPE)

Always utilize the most appropriate PPE during installation and service of Signet products.



Pressurized System Warning

Sensor may be under pressure, take caution to vent system prior to installation or removal. Failure to do so may result in equipment damage and/or serious injury.



DC Power Only